


First Step Stripping







Strip the cable about 7mm length.



Cable stripping steps finished.

Second S. Crimping



Put the metal pin to crimping tool tooth, and crimp lightly.



Put the stripped cable into the pin, crimp it tightly until loosen.



Pin crimping steps finished. Same as the other one.

Third Step Inserting



Put the crimped male pin into male housing tightly until it's set by "Click".



Put the crimped female pin into female housing tightly until it's set by "Click".



Use spanner to tighten the screw on both sides.

Fourth Step Connecting



Connect male and female.



Joint tightly until it's set by "Click". Open and joint easily by hand.

